

Table of Contents

Introduction	2
Required Materials	2
Diagram	3
Instructions for Use	3
Other Uses	4
Troubleshooting Suggestions	4
Safety Information	5

Instructions and Use of the EZ Charging Station

Introduction

The EZ Charging Station is a technological device that charges up to three handheld devices at one time. The devices do not need to be a particular make or model and only need to be rechargeable devices. The EZ Charging Station was designed to eliminate the need for multiple chargers as well to help in making life simpler for those that use multiple forms of technology.

Purpose

The EZ Charging Station allows users to recharge handheld devices that require many different chargers. Since people are currently using more handheld devices than ever before, it is important that there are products that cater to this growing field of users. The EZ Charging Station allows customers to charge multiple devices, from multiple companies with multiple uses all at the same time.

Description

The EZ Charging Station is a pyramidal-shaped charging device that sits on any level and flat surface. It has a ten inch diameter and is ten inches tall. It holds four handheld devices at any given time. It is made of various plastics. It comes in a variety of colors, as listed below:

- ◆ Black
- ◆ Blue
- ◆ Green
- ◆ Pink
- ◆ Silver
- ◆ Orange

Diagram



Required Materials

The EZ Charging Station requires very little. All you need is a flat, level surface and access to a proper form of electricity. The EZ Charging Station operates on the standard voltage of a household outlet, and can be used in any standard American outlet. The EZ Charging Station is also equipped for use with a battery pack that is old separately if an electrical outlet is unavailable.

Instructions for Use

1. Remove EZ Charging Station from box and discard all packaging materials.
2. Place EZ Charging Station on a flat and level surface near an outlet.
3. Plug Charging Station into proper outlet.
4. Place designated handheld devices within charging zones, as indicated on diagram.
5. Check that the Charging Indication Light is lit up.



Charging Station when being fully used

Note

A proper handheld device is determined as any of the following:

- ◆ Cell phone
- ◆ PDA
- ◆ iPod™ and iPhone™
- ◆ Any rechargeable MP3 Player
- ◆ Any handheld gaming devices (PSP™, Nintendo DS™) that are rechargeable
- ◆ Any rechargeable battery of a digital camera (place only the battery on the EZ Charging Station)

Laptops, remote controls, and non-rechargeable batteries are not considered rechargeable handheld devices.

Determining When Charging is Complete

The charging is complete when the Charging Indication Light has turned off. The EZ Charging Station will turn off automatically when charging is complete, and will not waste energy on unnecessary charging.

Other Uses

The EZ Charging Station can also be used as a night light. The lights are indicated in the diagram above as being on top of the station. The night light is a square that is 2.25 square inches. The light emits a yellow glow that gives off enough light to see the surrounding area. The instructions for the use of the night light are below.

Instructions for Night Light Use

1. Follow steps 1-3 in the instructions for use above.
2. Turn on switch as indicated in diagram above.
3. When finished using night light, turn switch to off position and un-plug if desired.



Note

The EZ Charging Station Night Light function uses LED lights to emit light. These are completely safe bulbs and do not warm quickly.

Troubleshooting Suggestions

If you are having trouble operating the EZ Charging Station, here are a few suggestions that may rectify the situation.

- ◆ Make sure the device is plugged into a properly powered and functioning outlet
- ◆ Check that batteries on the handheld devices are leaning back against the flat inclined surface and that the device is facing outward
- ◆ Check to see that the device being charged is one of the devices deemed proper in the above note
- ◆ Locate charging zones and be sure that the handheld device is within the designated area
- ◆ The EZ Charging Station will only charge one device per charging zone, so do not place more than one device per zone on the charging mat

If you are still having trouble after looking at these suggestions, please feel free to call our support services at 1-800-All-Tech. The Support Center is open from 9am to 9pm, Monday through Friday, and 10am to 6 pm on Saturday and Sunday.

Safety Information

The EZ Charging Station is an incredibly safe product to use, however you should look over the following safety suggestions to ensure you use the product correctly.

- ◆ Keep Charging Station away from water, children, and extreme heat
- ◆ Use proper 120 volt outlet for use
- ◆ As with any other technological device, the Charging Station may give off a small amount of radiation
- ◆ Keep product away from flammable materials
- ◆ As always, improper use of this product may lead to serious injury